

Semi-Custom Fit

Instructions for SOFA, LOVESEAT or CHAIR

It's as Easy as 7 Steps to a SURE FIT

1 LOCATE.....

the sewn-in "Center Front" and "Center Back" labels. Also look for the positioning stickers on the left and right arms.



2 DRAPE

First REMOVE seat cushions. Drape slipcover, pulling down over all the main parts of the furniture using positioning labels and stickers. Line up so cover is even with the floor on all sides.



3 TUCK INTO CREASES...

using the stitching and piping as a guide to line up along the edges. Tuck in excess fabric, pushing it down and under along the sides working from seat to back seams. Arm height and width can be adjusted.



4 SKIRT COVER

meets at back corners. Pull closed as you smooth fabric to fit your furniture using elastic band with fabric covering.



5 INSERT CUSHION(S).....

into zippered cover. You may need to overlap cushions when inserting them into a seat cover and then flatten them before you zipper the cover closed.



6 PLACE SEAT CUSHION(S)

with zippered closure facing the back. Push down front until flat. Smooth excess fabric and tuck creases on all three sides.



7 WHEN FINISHED

your slipcover should fit snugly, almost like it was custom-made. It's "sure" to make a positive impression!



NOTE: Arms should line up to flatter the width and shape of the original furniture style.